



# Advanced Wheelend Technologies

Service bulletin

## BBOC-FRU-1932 Bushing installation

### Bushing identification

BBOC-FRU-1932 Bushing	ORG-223 O-Ring

### Installation procedure

	Step 1; Install bushing as shown in training and procedure manual steps 2k Through 2v. In step 2n, use tool# BAC-1932 alignment sleeve instead of regular tool. <b>Keep in mind that this bushing has a pre-cut inner bore and does not need to be align-bored.</b>
	Step 2; After bushings have been align-bored and cleaned of all debris, install the ORG-223 O-Rings. <b>Lube O-Rings and the inner bore of the bushing before introducing the O-Rings into the bushings.</b>

For any questions regarding this service bulletin please use our toll free tech support line;

1 877 765 9629